
Thank you for purchasing the **QUQVE** brand series, which is the fullrange aluminum speaker specially designed for the non-destructive modification. They have all passed comprehensive tests to ensure its consistency and reliability.

- Before installing the mounting hole, please confirm that the installation space is appropriate.
- To prevent noise interference, make sure that the wiring is away from the engine, high voltage conductors and other potential sources of noise.
- To prevent short circuits, make sure that the wiring avoids moving parts and sharp edges.
- Before installing this product, please make sure that you have read this installation guide carefully.


ATM 1 TECHNICAL PARAMETERS:

MODEL	ATM 1
RMS Power	15W
Speaker	1*1.5" 4 ohm
Frequency Range	260Hz~20K Hz
Sensitivity@ 1W/1M	83 dB
Box	Aluminum
Dimension (LxWxH)	95x46x46 mm

Installation 1:



Installation 2:



Screw position

Use the screws to adjust the height of the speaker.

Pull the piston outside, adjust the gear in the direction of the arrow to change the angle of the speaker.

Use double sided tape to fix support.

amake

ATM 1

CAR FULLRANGE SPEAKER USER'S GUIDE